

Power, Performance & Perfection

The CMX Series

Material & Coating Thickness Gauges

ELECTRONIC PLATFORM

(What's inside the box):

- ▶ Powered by a 100MHz DSP platform using FPGA technology.
- ▶ Two Channels—Dual pulsers and receivers.
- ▶ Up to 140Hz pulse repetition rate.
- ▶ Display update rate of 25 times per second.
- ▶ Adjustable gain settings - vlow, low, med, hi, vhi.
- ▶ Automatic gain control (AGC).
- ▶ Time corrected gain (TCG).
- ▶ Massive data storage (32 Megabit of non-volatile RAM).

FEATURES:

- ▶ Measurement modes: Pulse-Echo, Pulse-Echo w/Coating, Pulse-Echo w/Temperature Compensation, Echo-Echo, & Coating Only.
- ▶ Automatic: probe zero, probe recognition, and temperature compensation.
- ▶ Stores up to 64 custom setups for specific applications.
- ▶ High Speed Scan of up to 50 readings per second.
- ▶ Audible/visual alarm with hi and lo limit settings.
- ▶ Built-in differential mode for QC inspections.
- ▶ Time based B-Scan feature for cross section material scans.
- ▶ Data storage formats: Alpha numeric grid and sequential w/auto identifier.
- ▶ Windows PC software included.
- ▶ 2 year limited warranty.

CMX AND CMX-DL SPECIFICATIONS

Physical

Size:

Width (2.5in/63.5 mm)
Height (6.5 in/165 mm)
Depth (1.24 in/31.5 mm)

Weight:

13.5 ounces (with batteries).

Keyboard:

Membrane switch pad with twelve tactile keys.

Operating Temperature:

14 to 140F (-10C to 60C)

Extruded aluminum body with nickel-plated aluminum end caps (gasket sealed).

Data Output:

Bi-directional RS232 serial port. Windows® PC interface software.

Display:

1/8in VGA grayscale display (240 x 160 pixels). Viewable area 2.4 x 1.8in (62 x 45.7mm). EL backlit (on/off/auto).

Ultrasonic Specifications

Measurement Modes:

Coating Off: Pulse-Echo (P-E)

Coating On: Pulse-Echo Coating (PECT)

Temp Comp: Pulse-Echo Temperature Compensation (PETP)

Thru-Paint: Echo-Echo (E-E)

Coating Only: Coating (CT)

Pulser:

Dual square wave pulsers.

Receiver:

Dual receivers—manual or AGC gain control with 110dB range (limited).

Timing:

Precision 25 MHz TCXO with single shot 100 MHz 8 bit ultra low power digitizer.



Power Source

Three 1.5V alkaline or 1.2V NiCad AA cells.

Typically operates for 150 hours on alkaline and 100 hours on NiCad (charger not included.)

Auto power off if idle 5 min.

Battery status icon.

Measuring

Range:

Pulse-Echo Mode (P-E)—(Pit & Flaw Detection) measures from 0.025 to 19.999 inches (0.63 to 508 millimeters).

Pulse-Echo Coating Mode (PECT)—(Material, Coating, Pit & Flaw Detection): Material: 0.025 to 19.999 inches (0.63 to 508 millimeters). Coating: 0.001 to 0.100 inches (0.01 to 2.54 millimeters).

Pulse-Echo Temp Comp Mode (PETP)—(Pit & Flaw Detection) Auto temperature compensation -measures from 0.025 to 19.999 inches (0.63 to 508 millimeters).

Echo-Echo Mode (E-E)—(Thru Paint & Coatings) measures from 0.100 to 4.0 inches (2.54 to 102 millimeters). Range will vary +/- depending on the coating.

Coating Only Mode (CT)—(Coating Thickness) Measures from 0.0005 to 0.100 inches (0.0127 to 2.54 millimeters). Range will vary +/- depending on the coating.

Resolution:

+/- 0.001 inches (0.01 mm)

Velocity Range:

0.0492 to 0.5510 in/ms
1250 to 13995 meters/sec

Single and Two point calibration option for material & coating, or selection of basic material types.

Units:

English & Metric

Display:

Large Digits—Standard thickness view. Digit Height: 0.700 inches (17.78 millimeters).

B-Scan—Time based cross section view. Display speed of 15 secs per screen.

Scan Bar Thickness—6 readings per second. Viewable in B-Scan and Large Digit views.

Repeatability Bar Graph—Bar graph indicates stability of reading.

Feature Status Bar—Indicates features currently active.

Data Logger (CMX-DL)

Log Formats:

Grid (alpha numeric)
Sequential (auto identifier)

Cell contents:

Graphics On: 16,000 readings, B-Scan image, & gauge settings for every reading.

Graphics Off: 210,000 readings (coating, material, min & max) OBSTRUCT to indicate inaccessible locations.

Memory:

32 megabit non-volatile ram.

Transducer

Transducer Types:

Dual Element (1 to 10 MHz).

Locking quick disconnect "00" LEMO connectors.

Standard 4 foot cable.

Custom transducers and cable lengths available for special applications.

Certification

Factory calibration traceable to national standards.

Warranty

2 year limited

A S O N A T E S T N D E G R O U P C O M P A N Y

Distributed by:



DAKOTA ULTRASONICS

300 El Pueblo Road, Suite 100

Scotts Valley, CA 95066

TELEPHONE: 831.431.9722

FAX: 831.431.9723

WEB SITE: www.dakotaultrasonics.com

E-MAIL: info@dakotaultrasonics.com