

# DAKOTA ULTRASONICS

## Performance, Power & Perfection!

### The CMX Series<sub>v2.0</sub> Material & Coating Thickness Gauges

#### Electronic Platform:

- ▶ Powered by a 100MHz DSP platform using FPGA technology.
- ▶ Two Channels - Dual pulsers and receivers.
- ▶ Up to 250Hz pulse repetition rate.
- ▶ Display update rate of 25 Hz.
- ▶ Adjustable gain (40 to 52 dB) - vlow, low, med, hi, vhi.
- ▶ Automatic gain control (AGC).
- ▶ Time dependent gain (TDG).
- ▶ 4 gigabyte internal SD memory card.

#### Features:

- ▶ Measurement modes: Pulse-Echo, Pulse-Echo w/Coating, Pulse-Echo w/Temperature Compensation, Echo-Echo, Echo-Echo Verify & Coating Only.
- ▶ Automatic: probe zero, probe recognition, and temperature compensation.
- ▶ Stores up to 64 custom setups for specific applications.
- ▶ High Speed Scan of up to 250 readings per second.
- ▶ Audible/visual alarm with hi and lo limit settings.
- ▶ Built-in differential mode for QC inspections.
- ▶ Time based B-Scan feature for cross section material scans.
- ▶ Data storage formats: Alpha numeric grid and sequential w/auto identifier.
- ▶ Windows PC software included.
- ▶ 2 year limited warranty.

SOUND SOLUTIONS

# CMX & CMX DL SPECIFICATIONS

## Physical

### Size:

Width (2.5in/63.5 mm)  
Height (6.5 in/165 mm)  
Depth (1.24 in/31.5 mm)

**Weight:** 13.5 ounces (with batteries).

**Keyboard:** Membrane switch pad with twelve tactile keys.

**Operating Temperature:**  
14 to 140F (-10C to 60C)

**Case:** Extruded aluminum body with nickel-plated aluminum end caps (gasket sealed).

**Data Output:** USB-C port. Windows® PC interface software.

**Display:** 1/8in VGA grayscale display (240 x 160 pixels). Viewable area 2.4 x 1.8in (62 x 45.7mm). EL backlit (on/off/auto).

## Ultrasonic Specifications

### Measurement Modes:

**Coating Off:** Pulse-Echo (P-E)

**Coating On:** Pulse-Echo Coating (PECT)

**Temp Comp:** Pulse-Echo Temperature Compensation (PETP)

**Thru-Paint:** Echo-Echo (E-E)

**Thru-Paint Verify:** Echo-Echo Verify (E-EV)

**Coating Only:** Coating (CT)

**Pulser:** Dual square wave pulsers.

**Receiver:** Dual receivers - manual or AGC gain control with 110dB range (limited).

**Timing:** Precision TCXO timing with single shot 100 MHz 8 bit ultra low power digitizer.

## Power Source

**Line power:** USB to PC or power outlet.

**Batteries:** Three AA cells.

Alkaline - grayscale 35 hrs, color 12 hrs.

Nicad - grayscale 10 hrs, color 5 hrs.

NI-MH - grayscale 35hrs, color 12 hrs.

Power saving DIM (color), auto off 5 minutes. Battery status icon.

## Transducer

Transducer Types:

Dual Element (1 to 10 MHz).

Locking quick disconnect  
"00" LEMO connectors.

Standard 4 foot cable.

Custom transducers and cable lengths available for special applications.

## Measuring

**Pulse-Echo Mode (P-E)** - (Pit & Flaw Detection) measures from 0.025 to 48.0 inches (0.63 to 1219.2 millimeters).

**Pulse-Echo Coating Mode (PECT)** - (Material, Coating, Pit & Flaw Detection); Material: 0.025 to 48.0 inches (0.63 to 1219.2 millimeters). Coating: 0.001 to 0.100 inches (0.01 to 2.54 millimeters).

**Pulse-Echo Temp Comp Mode (PETP)** - (Pit & Flaw Detection) Auto temperature compensation - measures from 0.025 to 48.0 inches (0.63 to 1219.2 millimeters).

**Echo-Echo Mode (E-E)** - (Thru Paint & Coatings) measures from 0.100 to 6.0 inches (2.54 to 152.4 millimeters). Range will vary +/- depending on the coating.

**Echo-Echo Verify Mode (E-EV)** - (Thru Paint & Coatings) measures from 0.100 to 1.0 inches (2.54 to 102 millimeters). Range will vary +/- depending on the coating.

**Coating Only Mode (CT)** - (Coating Thickness) Measures from 0.0005 to 0.100 inches (0.0127 to 2.54 millimeters). Range will vary +/- depending on the coating.

### Resolution:

+/- 0.001 inches (0.01 mm)

### Velocity Range:

0.0122 to 0.7300 inches/ $\mu$ s  
309.88 to 18542 meters/sec

Single and Two point calibration option for material & coating, or selection of basic material types.

### Units:

English & Metric

## Display

**Large Digits** - Standard thickness view. Digit Height: 0.700 inches (17.78 millimeters).

**B-Scan** - Time based cross section view. Display speed variable (10 to 200 readings per second).

**Scan Bar Thickness** - Speed 33 Hz. Viewable in B-Scan and Large Digit views.

**Repeatability Bar Graph** - Bar graph indicates stability of reading.

**Feature Status Bar** - Indicates features currently active.

## Memory (CMX DL)

**Log Formats:** Grid (Alpha Numeric), or Sequential (Auto Identifier).

**Capacity:** 4 Gb internal SD card.

**Screen Capture:** Bitmap graphic capture for quick documentation (.tif).

OBSTRUCT to indicate inaccessible locations.

## Connections

**Output:** Direct USB-C 1.1 PC connectivity.

**Transducer Connectors:** Two LEMO 00 connectors.

## Certification

Factory calibration traceable to NIST & MIL-STD-45662A.

## Warranty

2 year limited



# MADE IN THE USA

Distributed By:



## DAKOTA ULTRASONICS

1500 Green Hills Road, #107

Scotts Valley, CA 95066

Ph: (831) 431-9722

Fax: (831) 431-9723

Website: [www.dakotaultrasonics.com](http://www.dakotaultrasonics.com)

Email: [info@dakotaultrasonics.com](mailto:info@dakotaultrasonics.com)